



KORE Brake Cable Set Instruction Notes

Congratulations for buying the KORE flex-reducing bicycle brake cable system. For maximum safety concerning your purchase, please read the following information carefully.

Warning: Brake cable systems should be installed and serviced by qualified mechanics. If you are in doubt about your ability to do this yourself, go to your local bike shop and let them do it. They'll appreciate the business and you'll have peace of mind!

Each set contains:

- 6 x Ø6.0mm satin silver anodized alloy ferrules
- 2 x Ø5.7mm chrome-plated ferrules
- 2 x Ø1.5 x 2000mm double-end inner cable
- 1 x 3000mm x Ø5 multi-strand outer housing
- 2 x inner cable crimp ends

If any parts are missing, please go back to the store you purchased the cable set from to obtain replacements.

Important Note: Because of the special multi-strand construction of the outer housing, it is extremely important that ferrules are used to cover each open end of the housing - otherwise cable housing failure may occur resulting in loss of braking power. This includes housing insertion into road bike brake or brake/shift (Shimano, Campagnolo or SRAM) levers. For insertion into road bike brake or brake/shift levers, 2 x Ø5.7mm chrome-plated ferrules are provided. DO NOT ATTEMPT TO USE BRAKE CABLES WITHOUT FERRULES INSTALLED ON EACH OPEN END OF EACH PIECE OF OUTER HOUSING USED.

For more information or to ask a question, please visit our web site at www.kore-usa.com



www.kore-usa.com