



- \* Ergonomic shape improves comfort & reduces hand fatigue/numbness
- \* For single-groove drop handlebars with 95mm straight section
- \* Only 124g per pair

## Installation Instructions

- Make sure the brake cable housings are positioned in the grooves of the handlebar first!
- Remove all bolts and nuts then warm up the grips with a hair dryer or hot water to ease installation.
- From the back of the bar, push grips forward starting with the end closest to the stem until grip snaps over the handlebar and the opening is lined up with the brake cable. See inset photo for correct cable routing. Note that the brake housing runs BEHIND the grip clamp bolts.
- Install bolts and nuts taking care not to over-tighten. Bolts should be just tight enough to prevent grips from rotating but not so tight that the brake cable binds. Re-confirm correct brake cable function.
- Tape the rest of the handlebar, finishing at the outside end of the grip.



### WARNING:

- To be installed, adjusted and maintained by a skilled bicycle mechanic with the correct tools. If you are in doubt about your ability to do this yourself, take it to your local bike shop and let them do it. They'll appreciate the business and you'll have peace of mind.
- Do not attempt to modify this product as modification may result in product failure. Product failure could cause severe personal injury or even death. It also voids the warranty. So please don't do it.

### WARRANTY:

KORE products are covered by a limited life-time warranty. Those limits are:

- Applies to the original owner only – proof of purchase required.
- Wear and tear not included – if you like the product and wear it out, please buy another!
- Damage or failure due to an accident, trick or stunt riding. - however if we like your story, we might replace the part anyway. Its up to us though.

For more information, questions or comments, contact us at [www.kore-usa.com](http://www.kore-usa.com)